
Installation Instructions

Series 821




1. Cut out appropriate hole in required surface



| Luminaire Size | Cutout Ø |
|----------------|-----------|
| 113mm | 90-100mm |
| 145mm | 120-130mm |
| 174mm | 145-155mm |
| 205mm | 175-185mm |
| 232mm | 195-210mm |


2. Connect the driver in accordance with electrical regulations



3. Connect twist lock connector



4. Pull back springs and place into ceiling void



5. Power on Luminaire

